

-> Download the firmware-file for your ROXX fixture from the support-site:

<https://roxxlight.com/support/>

-> Copy the file to an USB stick into the root directory and not into a folder.
The stick must not be bigger than 8 GB memory capacity and should be "fat32" formatted.

Now there are two possibilities to proceed:

A: Fixture is switched off.

- > Connect the USB stick to the USB port of the ROXX Fixture.
- > Power up the unit.
- > Now the content of the USB stick is displayed. Using the arrow up/down buttons navigate to the correct firmware file and press "Enter"
- > Toggle "off" to "on" with the arrow buttons and confirm again with "Enter".
- > The update starts.

B: Fixture is powered up already.

- > Connect the USB stick to the USB port of the ROXX Fixture.
- > Press "Enter" to access the main menu. Now navigate to "Settings -> USB Update"
- > Select "Yes" and press "Enter" again
- > Now the content of the USB stick is displayed. Using the arrow up/down buttons navigate to the correct firmware file and press "Enter"
- > Toggle "off" to "on" with the arrow buttons and -> The update starts.

After the update, regardless of how it was started, the unit will ask if you want to do a factory reset. After 10 seconds without selecting "Yes" or "No" the unit will start automatically without doing a reset.

To be sure, that all software modifications are implemented correctly it's recommended to do the reset.

Tip: It's possible to update several, daisy chained units at the same time, but we recommend to do the update on only up to 8 units simultaneously.