

ROXX NEO

Wash-/Flood-Light

000 - 005 **FULL ON**



031 - 035 **BOUNCE A3**



006 - 010 **PULSE A1**



036 - 040 **2 BLOCKS**



011 - 015 **PULSE A2**



041 - 045 **RANDOM**



016 - 020 **PULSE A3**



046 - 050 **FILL IN**



021 - 025 **BOUNCE A1**



051 - 055 **FILL OUT**



026 - 030 **BOUNCE A2**



056 - 255 **FULL OFF**

